FIG.1

CORPORATE HEADQUARTERS

SERVER
USER
ROUTER
CoSine InGage
16

FR, IP
FT1,
T1/E1,
FT3, T3,
OC-3

INTERNET

10

12

CoSine IPSX 9000

EDGE

14

ACCESS CONCENTRATION

CoSine InVision

SNMP

SERVICE PROCESSING

SP IP OR ATM CORE

FRAME RELAY SWITCH

CoSine IPSX 9000

L2TP, IPSec

DIAL-UP RAS

12

M13 MUX

DSLAM

CORPORATE REMOTE OFFICE

ROUTER

SERVERS

USERS

USERS

USERS

DIAL-UP TELECOMMUTER

IPSec, PPTP

MODEM

LAPTOP

FIG.2

CBR — 26

IPNOS APPLICATION OBJECTS

VIRTUAL ROUTER OBJECTS

LINK LAYER OBJECTS

DEVICE DRIVER OBJECTS

20

OBJECT MANAGER (OBJECT, GROUPS, OBJECT REGISTRATION, OBJECT METHOD INVOCATION, ETC.)

SYSTEM OBJECTS (RESOURCE MANAGER, RESOURCE LOCATION SERVER/CLIENT)

24

22

DML

OBJECT COMMUNICATION SERVICES

OBJECT LQ'S

PEER-PEER TRANSPORT (LOGICAL QUEUES (LQ) USED TO STEER TRAFFIC)

FILE IO TERMINAL IO

TASKS LOCKS SYNCHRONIZATION MEMORY

pSOS

FIG.3

FIG.4

APPS
OBJECT

APPS
OBJECT

APPS
OBJECT

APPLICATIONS
CLASS

50

TCP/IP
OBJECT

TCP/IP
OBJECT

TCP/IP
OBJECT

TCP/IP
CLASS

52

OBJECT
GROUP 1

OBJECT
GROUP 2

OBJECT
GROUP 3

IF
OBJECT

INTERFACE
CLASS

54

IF
OBJECT

IF
OBJECT

FIG.5

FIG.6

FIG.7

FIG.8

FIG.9

FIG.10

| STATE	EVENT	ACTION
START	TIMEOUT && (REQUEST COUNT < MAX)	SEND UPDATE REQUEST
START	TIMEOUT && (REQUEST COUNT > MAX)	PEER DID NOT REPLY. UPDATE FAILED TRANSIT TO FINISH STATE.
START	RECV UPDATE GROUP MESSAGE	TRANSIT TO UPDATE GROUP STATE. SET LAST UPDATE EQUAL TO THE CURRENT TIME.
START	RECV UPDATE OBJECT MESSAGE	TRANSIT TO UPDATE OBJECT STATE. SET LAST UPDATE EQUAL TO THE CURRENT TIME.

FIG.11

FIG.12

FIG.13

Srv_func

Obj_comm_t

Obj_2
Obj_2_recv

FUNC
OBJECT

FUNC
OBJECT

FUNC
OBJECT

REMOTE
SCB

REMOTE
CEP-ID

REMOTE
CEP-ID

REMOTE
SCB

FUNC
OBJECT

FUNC
OBJECT

Obj_1
Obj_1_recv

Obj_comm_t

FIG.14

Srv_func

Obj_comm_t

Obj_2
Obj_2_recv

FUNC
OBJECT

FUNC
OBJECT

FUNC
OBJECT

REMOTE
SCB

REMOTE
CEP-ID

REMOTE
CEP-ID

REMOTE
SCB

FUNC
OBJECT

FUNC
OBJECT

FUNC
OBJECT

Obj_1
Obj_1_recv

Srv_func

Obj_comm_t

FIG.15

STEP	LOCAL CEP OBJECT	LOCAL IPNOS	LOCAL RM/LQ	REMOTE RM/LQ	REMOTE IPNOS	REMOTE CEP OBJECT
1	obj_associa te_channel(local_chan, local_cep_id, remote_cep_id)					
2		/* Allocate remote LQ */ resmng_alloc_ resource (RESOURCE _DATA_CON NECTION, 0, remote_cep_id -> object.address _space_id, &remote_lq)				
3				Lookup resource tag and allocate from remote LQ		
4		/* Ask remote LQ to allocate local LQ*/ status = omori_obj_ioc tl_by_id (&remote_lq, remote_lq.gro up, OBJ_CTL_C ODE_ANY (LQUSER_BI ND), &lq_bind, sizeof (lq_bind)); memcpy (&local_lq,				

FIG.16a

		&lq_bind.lq_object.local, sizeof (object_id_t));			
5				Use resmng_alloc_resource() to allocate *local* LQ	
6			Lookup resource tag and allocate from *local* LQ		
7				Return allocated *local* LQ	
8		/* Bind Local and Remote LQs*/ status = omori_obj_ioctl_by_id (&local_lq, local_lq.group, OBJ_CTL_CODE_ANY (LQUSER_BIND), &lq_bind, sizeof (lq_bind));			
9			Setup LQ-API parameters to point to *remote* LQ	Setup LQ-API parameters to point to *local* LQ	
10		/* Push local LQ as a service onto local channel*/ status = omori_obj_ioctl_by_id			

FIG.16b

|						
		(&local_lq, local_lq.group, OBJ_CTL_C ODE_ANY (LQUSER_BI ND), &lq_bind, sizeof (lq_bind));				
11	Lookup CEP address					
12					/* Push remote LQ as a service onto remote channel*/ status = omori_obj_ioc tl_by_id (&remote_lq, local_lq.group, OBJ_CTL_C ODE_ANY (LQUSER_BI ND), &lq_bind, sizeof (lq_bind));	
13						Lookup CEP address

FIG.16c

FIG.17

FIG.18

STEP	OMCD	OMORIG	OMORI	OBJECT
0	Create unique vr_descriptor_t for specified VPN, fills with default value and adds VR to the list of VR per VPN.			
1	Requests group creation for specified VR with class_group_selector on specified address space.			

FIG.19a

2		Create group 1; create object id link of selected class. Validate address space id on capability to service specified object class. Send request CREATE_OBJECT to capable OMORI (2). Wait for OMORI reply.		
3			Receive CREATE_OBJECT request for specified group. Lookup a group; not found. Create group 1; Create object descriptor of selected class. Call the class constructor.	
4		Receive MV_OBJ_TO_GROUP request; add object id to OMORIG Database	add object to the group, send MV_OBJ_TO_GROUP request to OMORIG	
5				Create and initialize an object; return SUCCESS or FAILURE.
6			If FAILURE remove object from the group, send MV_OBJ_TO_GROUP and RM_OBJ_FROM_GROUP to OMORIG; ================ Else send reply for CREATE_OBJECT request to OMORIG	
7		Receive MV_OBJ_TO_GROUP request, move object to the group 0(OM_BASE_GROUP); Receive RM_OBJ_FROM_GROUP request; remove object id from OMORIG		

FIG.19b

|		Database		
		================		
8		Receive Object CREATE reply. Signal to OMCD		
9	VR created, return status to user			
10		Send ACTIVATE object message to OMORI (2)		
11			Receive ACTIVATE object message. For all the objects of this group send generic IOCTL ACTIVATE_OBJECT	Activate object, Do object-specific action to make it active, operational

FIG.19c

FIG.20

STEP	OMCD	OMORIG	OMORI	OBJECT
0	Create unique vr_descriptor_t for specified VPN, fills with default value and adds VR to the list of VR per VPN.			
1	Requests group creation for specified VR with class_group_selector on specified address space.			
2		Create group 1; create object id link of selected class. Validate address space id on capability to service specified object class. Send request CREATE_OBJECT to capable OMORIs (1 and 2). Wait for reply from both OMORIs.		
3			Receive CREATE_OBJECT request for specified group. Lookup a group; not found. Create group 1; Create object descriptor of selected class. Call the class constructor.	
4		Receive MV_OBJ_TO_GROUP request; add object id to OMORIG Database	add object to the group, send MV_OBJ_TO_GROUP request to OMORIG	
5				Create and initialize an object; return SUCCESS or FAILURE
6			If FAILURE remove object from the group, send MV_OBJ_TO_GROUP and RM_OBJ_FROM_GROUP to OMORIG;	

FIG.21a

|			Else send reply for CREATE_OBJECT request to OMORIG	
7		Receive MV_OBJ_TO_GROUP request, move object to the group 0(OM_BASE_GROUP); Receive RM_OBJ_FROM_GROU P request; remove object id from OMORIG Database		
8		Receive Object CREATE reply. If all the object replied then signal to OMCD, otherwise do nothing		
8	VR created, return status to user			
10		Send ACTIVATE object message to every OMORI (1,2) where objects were created		
11			Receive ACTIVATE object message. For all the objects of this group send generic IOCTL ACTIVATE_OBJECT	
12				Activate object, Do object-specific action to make it active, operational

FIG.21b

FIG.22

STEP	OMCD	OMORIG	OMORI	OBJECT
0	For specified VPN and VR lookup vr_descriptor. Call OMORIG to delete corresponding group.			
1		Lookup group descriptor by specified id. Filter OMORIs which have objects to be destroyed(which belong to the specified group)		
2			Receive DESTROY_GROUP_OBJECTS request for specified group. Lookup a group; Send generic IOCTL STOP_OBJECT to every local object, which belongs to the group	
3				Stop operating, destroy all connections with other objects

FIG.23a

| 4			Send generic IOCTL DESTROY_OBJECT to every local object, which belongs to the group	
5				Free itself
6			If FAILURE remove object from the group, send MV_OBJ_TO_GROU P and RM_OBJ_FROM_GR OUP to OMORIG;	
7		Receive MV_OBJ_TO_GROUP request, move object to the group 0(OM_BASE_GROUP); Receive RM_OBJ_FROM_GROU P request; remove object id from OMORIG Database		
8		Receive Object DESTROY_GROUP_OBJ ECTS. Subtract number of destroyed objects from the total number of objects in the group (VR). If all objects destroyed then signal to OMCD, otherwise do nothing.		
8	VR destroyed, return status to user			

FIG.23b

| CBR | 26 |

| OM | 24 | | CB CHANNEL | 25 |

| DML | 22 |

| CONTROL RING | 23 |

FIG.24

FIG.25

FIG.26

FIG.27